

Lech Tech

Simple Mode - HOUSE LIGHTING

The House Lights in Leconfield Hall Auditorium are controlled from either of two control pads. One is situated at the back of the room, by the lift, one is in the tech booth.

The control pads look like this:



1 - Select a lighting scene. Recall one of four present lighting scenes, numbered 1-4. Select OFF to turn off.

1. Full - inc stage
2. Full - ex stage
3. Mid - preshow/audience arrival
4. Low - intimate, used for cinema trailers etc

The bar area remains lit in scenes 3 & 4, in proportion to the room level.

2 - Use the UP and Down arrow keys to adjust your selected scene.

3 - Use the Rako app to control the room. Please make sure you've connected to the Lec Tech wifi and downloaded the app. You can make adjustments to individual zones on the app.

PLEASE DO NOT OVERWRITE ANY SCENES
while using the Rako app as these are venue defaults.

NB. The cinema system also controls the house lights, and films will automatically dim and brighten the house lights as the films start playing.